



HOW TO RELEASE THE SHACKLE ON YOUR SENTRIGUARD® KEYBOX

Be sure that the app and the keybox firmware have both been updated.

✓ Open SentiKey App

Open the SentiKey App and press 'Release Shackle' from the home screen.

✓ Wake Your Box

Press ENT on your keybox to initiate communication.

✓ Authorize


Use your PIN or biometrics to authorize the app, then follow the prompts.

✓ Remove Shackle

While holding the box, push down on the shackle, then pull up to release.

✓ WAIT!

It is important to wait until you hear the box finish its mechanical cycle (about 30 seconds) before reattaching the shackle.



THE
CINCYMLS

TUESDAY TIP
07/04/23